

SINGER®

A black, rectangular bag with a top handle and a shoulder strap. The word "SINGER" is printed in red capital letters on the front. There is a small zippered pocket on the front, and a metal clasp is visible on the left side.

www.singerdeutschland.de

Technische Daten

Maße Tasche	L 457 mm / B 254 mm / H 330 mm
Maße Karton	L 495 mm / B 80 mm / H 330 mm
Gewicht Tasche	1,23 kg
Gewicht Tasche plus Karton	1,55 kg
Farbe	schwarz
EAR	WEEE Reg. Nr. DE61309878
EAN Code	7393033158248
Zolltarifnummer	84521090