KALKBUSTER

DE Gebrauchsanleitung

Liebe Kundin, lieber Kunde,

wir freuen uns, dass du dich für den **KALKBUSTER Wasserhahn-Entkalker** entschieden hast. Solltest du Fragen zum Produkt haben, wende dich an den Kundenservice über unsere Website:

www.die-millionenidee.de

Informationen zur Gebrauchsanleitung

Lies vor dem ersten Gebrauch des Produktes die Gebrauchsanleitung sorgfältig durch und bewahre diese für spätere Fragen und weitere Nutzer auf. Sie ist ein Bestandteil des Produktes. Hersteller und Importeur übernehmen keine Haftung, wenn die Angaben in dieser Gebrauchsanleitung nicht beachtet werden.

Wichtige Hinweise

- Das Produkt dient zur **äußeren** Entfernung von Kalk an allen gängigen Wasserhähnen mit einem Durchmesser von 16 – 28 mm.
- Das Produkt ist **nicht** für innen liegende Siebeinsätze geeignet.
- Das Produkt ist für den privaten Gebrauch, nicht für eine gewerbliche Nutzung bestimmt.
- Das Produkt nur für den angegebenen Zweck und nur wie in der Gebrauchsanleitung beschrieben nutzen. Jede weitere Verwendung gilt als bestimmungswidrig.
- Von der Gewährleistung ausgeschlossen sind alle Mängel, die durch unsachgemäße Behandlung, Beschädigung, Verkalkung oder Reparaturversuche entstehen. Dies gilt auch für den normalen Verschleiß.
- **Kinder** dürfen **nicht** mit dem Produkt spielen.
- Keine scharfen oder scheuernden Reinigungsmittel verwenden! Bei Bedarf unter fließendem Wasser reinigen oder mit einem feuchten Tuch abwischen.
- Das Produkt an einem sauberen, trockenen, für Kinder und Tiere unzugänglichen Ort aufbewahren.

Lieferumfang

1 x Wasserhahn-Entkalker
1 x Gebrauchsanleitung

Den Lieferumfang auf Transportschäden überprüfen. Bei Schäden nicht verwenden, sondern den Kundenservice kontaktieren. Eventuelle Folien, Aufkleber oder Transportschutz vom Produkt abnehmen.

Benutzung

1. Der Siebeinsatz des Wasserhahns muss für die Anwendung **nicht** ausgebaut werden!
   Den Bürstenaufsatz über das Ende des Wasserhahns stülpen und mehrfach hin- und herdrehen. Dabei **nur leichten Druck ausüben**, um den Siebeinsatz nicht zu beschädigen.
2. Anschließend kurz spülen, um gelösten Kalk zu entfernen.
3. Bei verbleibenden Kalkresten den Vorgang ggf. wiederholen.
4. Nach der Benutzung den Wasserhahn-Entkalker durch leichtes Abklopfen vom Kalk befreien oder kurz ausspülen. Anschließend umgedreht mit den Borsten nach unten trocknen lassen.

Entsorgung

Das Verpackungsmaterial umweltgerecht entsorgen und der Wertstoffsammlung zuführen. Das Produkt kann über den Hausmüll entsorgt werden.

Produktdaten

Artikelnummer:	30151
ID Gebrauchsanleitung:	Z 30151 M DS V1 0426 fd

EN Operating Instructions

Dear Customer,

we are delighted that you have chosen the **KALKBUSTER faucet descaler**. If you have any questions about the product, please contact the customer service department via our website:

www.die-millionenidee.de

Information about the operating instructions

Before using the product for the first time, please read through these operating instructions carefully and keep them for future reference and other users. They form an integral part of the product. The manufacturer and importer do not accept any liability if the information in these operating instructions is not complied with.

Important Notes

- This product is for the **external** removal of limescale from all standard faucets with a diameter of 16 – 28 mm.
- This product is **not** suitable for internal aerators.
- This product is intended for private use only, not for commercial use.
- Use the product only for its intended purpose and only as described in the instructions for use. Any other use is considered improper.
- The warranty excludes all defects caused by improper handling, damage, limescale buildup, or attempted repairs. This also applies to normal wear and tear.
- **Children** must **not** play with the product.
- Do not use harsh or abrasive cleaning agents! If necessary, clean under running water or wipe with a damp cloth.
- Store the product in a clean, dry place, out of reach of children and animals.

Items Supplied

1 x Faucet descaler
1 x Operating Instructions

Check the content for transport damage. If you find any damage, do not use the product but contact our customer service department.

Remove any possible films, stickers or transport protection from the product.

Use

1. The faucet aerator does not need to be removed for use!
   Place the brush attachment over the end of the faucet and twist it back and forth several times. Apply only light pressure to avoid damaging the aerator.
2. Then rinse briefly to remove dissolved limescale.
3. Repeat the process if limescale residue remains.
4. After use, remove limescale from the faucet descaler by gently tapping it or rinsing briefly. Then turn it upside down with the bristles facing down and allow it to dry.

Disposal

Dispose of the packaging material in an environmentally friendly manner so that it can be recycled. If the product is no longer going to be used, dispose of it in an environmentally friendly manner as well.

Product Data

Article number:	30151
ID operating instructions:	Z 30151 M DS V1 0426 fd

Hersteller | Manufacturer:
DS Produkte GmbH Stormarnring 14, 22145 Stapelfeld, Deutschland | Germany
Kundenservice | Customer Service:
Am Heisterbusch 1, 19258 Gallin, Deutschland | Germany
service@die-millionenidee.de